



MANUAL PUMP MODELS
 MODELES DE POMPE MANUELLES
 MODELOS DE BOMBAS MANUALES



AUTOMATIC PUMP MODELS
 MODELES DE POMPES AUTOMATIQUES
 MODELOS DE BOMBA AUTOMATICA



REPLACEMENT PARTS LIST

Item No.	Part No.	Description	6-CIM	6-CIA
1	108101	Handle, Pump	1	1
2	928004	Seal Ring	1	1
3	108029	Pump Base, Air Bleed, Blue	--	1
3	108034	Base, Pump, Blue	1	--
4	909021	Screw/Washer #10-24 x 1/2"	5	5
5	108082	Screen, Intake	1	1
6	928028	Seal Ring	1	1
7	108050	Housing Assembly, Automatic, 8'	--	1
7	108069	Housing Assembly, Manual, 12'	1	--
8	108202	Bracket, Switch	--	1
9	951961	Lead Wire Assembly	--	1
10	924001	O-Ring	--	2
11	950323	Switch, Miniature	--	1
12	599026	AD-6 Adaptor	1	1
13	902404	Screw, Tap #8-18 x 3/8"	--	1
14	108125	Diaphragm	--	1
15	108055	Cover, Automatic Switch Housing	--	1
16	909027	Screw/Washer #10-24 x 1-3/4"	--	4
16	909024	Screw/Washer #10-24 x 1-3/8"	4	--
17	921023	Washer, #10 Lock	1	1
18	901529	Screw, Machine #10-24 x 1/4"	1	1